

## **Feature Reference Guide**

Fleet View	Real-Time Location Features	
Data View	Data View shows the most recent updates for the units in your fleet, providing you a snapshot of where your vehicles are right now.	
Map View	Map View displays all of your units' correct locations on a map. If you are using dash cameras, you can click on a vehicle's icon to stream the camera video in real-time.	
Vehicle Vitals	Vehicle Vitals displays the current health status of your vehicles, including metrics such as battery voltage, check engine light status, etc.	
<b>⊘</b> Behavior ∨	Driver Behavior Monitoring Features	
Fleet Sustainability	The Fleet Sustainability Report helps companies determine how much fuel is wasted and how much CO2 is emitted due to poor driving habits such as excessive idling & speeding.	
Trends	The Trends Report gives you a high level view of a vehicle's idling, speeding, and mileage compared to the entire fleet.	
Benchmarks	The Benchmarks Report shows how your fleet compares to other fleets in the same region and industry for aggressive driving and speeding events.	
Safety Scorecard	The Safety Scorecard scores your drivers based on the number of aggressive driving, speeding, and posted speed limit violations.	
Projections	The Projections report forecasts future idling, speeding, and mileage based on the historical trends	
Aggressive Driving	The Aggressive Driving report displays location and time details for all aggressive driving events.	


Crash Risk	The Crash Risk report uses AI to predict crash risk by driver based on factors such as driver behavior and the local weather forecast.	
→ Dispatch	Dispatch Features	
Dispatch View	In Dispatch View, you would assign routes and individual stops to your drivers to be sent to their in vehicle navigation device or Goose mobile app. You can also send messages to drivers and monitor their current route progress.	
Route Creator	In Route Creator, you could plan, optimize, and save your drivers' daily routes.	
Dispatch Messages	In Dispatch Messages, you can communicate with individual drivers, groups of drivers, or your entire fleet via 2 way messaging in the Goose app.	
Reports V	Reports	
Breadcrumb History	Breadcrumb History displays a "breadcrumb" trail of a unit's past path of travel.	
Asset Activity	Asset Activity allows you to view a detailed list of updates for your units from when the devices were first installed in your assets.	
Stop Details	Stop Details allows you to view all stops units have made over any specified time period.	
Search Location	Search Location allows you to enter an address and see when units were at that location during any time period.	
Notifications	Notifications display any rule violations by any units in the fleet.	
Asset Landmark	Asset Landmark displays each time a unit entered and existed any landmark.	
Landmark Stops	Landmark Stops displays each time any unit entered and exited a specific landmark.	
Start End	Start End allows the user to view the first ignition on and last ignition off for each day.	
Job End	Job End displays each unit's first entry into the first landmark and last exit from the last landmark each day.	
Distance Travelled	Distance Traveled displays the total distance traveled for all units during a specific time period.	
Speeding	The speeding report displays all travelling speeds along with the streets' posted speed limits.	
Distance by State	Distance by State displays the total distance traveled for all units within specific states.	
Idle Summary	Idle Summary shows total idle time over an extended period of time (i.e. month, quarter, year)	
Idle Time	Idle Time displays each time a unit idled during a specific time range.	
Distance by County	Distance by County displays distance travelled within each geographic county boundary over a certain period of time.	

Inspection	The Inspection report displays all vehicle inspection reports completed by drivers.	
Diagnostic Codes	The Diagnostic Codes report displays all diagnostic trouble codes (DTC's) triggered by vehicles during a certain period of time.	
Device Health	Device Health shows the strength of the GPS signals received by the devices. It is a useful aid in determining whether devices are being tampered with.	
Power Disconnect	The Power Disconnect report displays each time a device was unplugged from its power source. It is a useful aid in determining whether devices are being tampered with.	
Engine Time	Engine Time is used to monitor each time a unit started and stopped operating and its total operating hours during a specific time period.	
Dispatch History	Dispatch History displays records of all stops dispatched to drivers, including times sent, times received, and times arrived at jobsites. It also includes proof of service records.	
Timeclock History	Timeclock History displays all clock in and clock out records by your employees, including times and locations.	
Dispatch Activity	The Dispatch Activity report displays a record of all dispatch stops, when ETA message and proof of service receipts were sent to clients, and your clients' feedback and survey results from stops.	
User Activity	User Activity displays all logins and page views by your users.	
Fuel Card	The Fuel Card report displays all fuel transactions and matches them with the vehicles' actual locations when the fuel cards were used. This helps to identify potential fuel card fraud.	
Device Status	The Device Status report displays all of your devices, the vehicles they are assigned to, the order dates, ship dates, installation dates, and activation dates.	
Camera Events	The Camera Events report displays any events that were triggered by your cameras. This could include accidents, speeding violations, cell phone use, etc.	
Camera Recordings	The Camera Recordings displays video of driving activity. You can run a report to retrieve video from a specific point in time in the past that did not trigger an event.	

Maintenance	Maintenance Features
Manage Schedules	Manage Schedules allows you to create schedules for an unlimited number of maintenance reminders.
Schedule Summary	Schedule Summary allows you to see the status of all scheduled maintenance reminders that you created.
Settings V	

Company Information	Company Information allows you to modify the company's contact information, the default map and your industry classification for the Benchmarks report.	
Manage Fleet	Manage Fleet allows you to edit Vehicle Labels, VIN numbers, years, makes, models, and unit icon colors. You can also assign trackers and cameras to your assets.	
Manage Locations	Manage Locations allows you to create and edit as well as delete landmarks and restricted zones.	
Manage Users	Manage Users allows you to create sub-users and set their access rights.	
Manage Drivers	Manage Drivers is used by Goose dispatching users to setup drivers and provide them with access to the Goose dispatching app.	
Manage Groups	Manage Groups allows you to create groups containing different assets and specify which users are allowed to view each group.	
Manage Notifications	Manage Notifications allows you to set up rules for units and allows you to specify how you wish to be notified when an alert occurs.	
Report Scheduling	Report Scheduling allows you to configure the report you wished emailed, frequency of email, and the type of exported file you wish to receive.	

## **Support Options**



Visual Notifications	This shows the number of unviewed visual notifications. Click the link to view a dropdown of each type of notification. Click on the notifications to go to a report.
Tutorial Video	The Tutorial Video link on the top of right shows you how to use each page on the site.

Copyright © 2010 – All Rights Reserved - FieldLogix – 888-803-0200